

# DOMESTIC SEWING MACHINE TROUBLE SHOOTING

**BEFORE YOU FREAK OUT DO THESE FIRST!!**

## THREAD & THREADING

**1** Are you using Good Thread. Top & Bottom

Good thread is Seralon. If you are not paying at least R25 / Spool you are nit using good thread

**2** Have you re-threaded top and bottom thread

Even if you think you know how to do threading just re-do to be sure

**3** Make sure nothing stuck in top thread tension plate

Use some Gum Floss to run through to be sure

**4** Thread goes through Needle from front to back no knot

## NEEDLE

**1** Does your needle match with fabric you are sewing?

**2** Is needle damaged if unsure replace

**3** Are you using Good Quality Needles like Schmetz

**4** Make sure needle is correctly inserted Pushed in as high as it can go.

## BOBBIN

**1** Are you using the correct bobbin that came with your machine

**2** Do you have correct & good thread on the bobbin

**3** Re-Thread bobbin

## INNER ROTARY HOOK ( BOBBIN CASE)

**1** Clean your Inner Rotary hook and the inside of machine

**2** Check for broken pieces of needles

**3** Check that there is no marks or nicks in the inner rotary hook

## NEEDLE PLATE & PRESSER FOOT

**1** Check your needle plate for marks and hooks

**2** Make sure your needle is going through presser foot without touching the presser foot