# picnic 4 one tote

#### **WATCH THE VIDEO TUTORIAL:**



Youtube: <a href="https://www.youtube.com/watch?v=98v7n8yRDG4">www.youtube.com/watch?v=98v7n8yRDG4</a>

# **PRINTING INSTRUCTIONS:**

- Print only the first page with 1x1 inch and/ or 2x2 cm blocks on the first page
- Set printer to 100% scale
- Avoid "Print Entire Image" or "Fill Entire Paper" options, as this will make your pattern print at the wrong size
- Measure printed 1x1 inch & 2x2 cm blocks with a ruler for accuracy
- If sizing is correct, print all pages at 100% scale
- Assemble and cut out the pattern

#### **SUPPLIES & TOOLS:**

The items listed are conveniently hyperlinked to their respective pages on the Fabric8 website, if available. Simply click on the desired item, and it will effortlessly open up in your web browser for easy access and purchase.

#### **Fabric:**

• 1m

#### **Supplies:**

Fusing

#### **Tools:**

- Sewing machine bobbins
- Fabric scissors
- Fabric marker/ tailors chalk
- Pins
- Fabric clips
- Prym mini steam iron
- Table sized ironing board
- Rotary cutter
- Self-healing cutting mat
- Quilting ruler
- Paper scissors
- Paper glue

#### 1. PREPARING THE MATERIALS


- Cut 2 Fabric Outer Tote Pieces on fold (Mark center at fold and note all other pattern markings on both pieces).
- Cut 2 Fusing Outer Tote Pieces on fold (Cut these 1cm smaller and fuse to the wrong side of the Fabric Outer Tote Pieces).
- Cut 1 Inner Plate Pocket on fold.
- Cut 1 Inner Utensil Pocket on fold.
- Cut 2 Tote Handles on fold OR use the pattern for the length of strapping.

#### 2. PREPARING INNER POCKETS


- Fold the Inner Plate and Utensil Pocket pieces with wrong sides together and topstitch the folded edge.
- Iron and pin or baste the raw edges neatly for the next steps.

#### 3. ATTACHING INNER PLATE POCKET

• Lay one of the Outer Tote pieces right side up, ensuring all pattern markings are visible.




• Pin and sew the Inner Plate Pocket to the Outer Tote piece as indicated in your pattern.




• Fold back the Inner Plate Pocket and topstitch over the fold. Baste the sides of the pocket together with the sides of the Outer Tote.

### 4. PREPARING & ATTACHING INNER POCKET

- Mark the divisions for knife, fork, spoon, and straw on the Inner Utensil Pocket piece.
- Attach the Inner Utensil Pocket to the Outer Tote piece in the same manner as the Inner Plate Pocket.



• Sew through the Inner Utensil Pocket and the Outer Tote along the marked lines to create individual pockets for each utensil.




#### 5. ATTACHING TOTE STRAPS

• Pin the Tote Straps in place as indicated in your pattern.

#### 6. ASSEMBLING THE TOTE

- Place the second Outer Tote piece on top of the first, with right sides facing each other.
- Pin around the edges, leaving a 10-15cm opening for turning the tote right side out.




- Sew around the pinned area, leaving the turning opening unsewn.
- Trim the seam allowances and turn the tote right side out.


### 7. FINISHING TOUCHES

- Iron the tote flat and topstitch around the edges.
- Now your Picnic 4 One Tote is ready for use. Enjoy your picnic!

#### **PRINTING INSTRUCTIONS:**

- 1. Start by only printing this page with the measurement scale (as below).
- 2. Ensure that your printer settings are correct:
  - Set your printer to "Do not scale" or to "100% scale". Set to A4.
  - Make sure that you have <u>not</u> selected "Print entire image" or "Fill entire paper". This will make your sizing incorrect.
  - You have to print your pattern at 100% scale.
- 3. Using a ruler or measuring tape, measure the inches or centimeters on the measurement scale below once this page has been printed out. Ensure that the measurement scale lines up with your ruler or measuring tape. If it does, it means you have selected the correct printer settings.
- 4. If your measurement scale lines up correctly, print out the rest of the pattern pages at 100% scale.
- 5. Cut out and line up the lines of the pattern pages. Ensure that the triangles in the corner all line up. Stick your pattern together as illustrated below.






This pattern/ document is protected by **copyright** law. It **may not be reproduced, distributed, or sold** in any form without the explicit written permission of Fabric8 Pty Ltd. However, you are allowed to create items using this pattern for personal use or for sale. Please tag us on social media when you showcase items made from this pattern. We would love to see your creations.




# STRAW


Summer Picnic
Summer Picnic
Picnic 4 One Tote
IINNER UTENSIL POCKETS
Cut 2 x Inner Fabric
Icm Seam Allowance Incl

Attach Inner
Pocket











# **OUTER TOTE**

Cut x 2 Outer Fabric Cut x 2 Fusing Icm Seam Allowance Incl

